

SITRANS

Pressure transmitter SITRANS P280 WirelessHART

Operating Instructions

<u>Introduction</u>	1
<u>Safety notes</u>	2
<u>Description</u>	3
<u>Commissioning (hardware)</u>	4
<u>Operation (hardware)</u>	5
<u>Installing / mounting</u>	6
<u>Connecting</u>	7
<u>Alarm, error, and system messages</u>	8
<u>Troubleshooting/FAQs</u>	9
<u>Appendix</u>	A

7MP1120D*, E*, F*, G*, H* Relative pressure
7MP1120M*, N*, P*, Q*, R* Absolute pressure

Legal information

Warning notice system

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. The notices referring to your personal safety are highlighted in the manual by a safety alert symbol, notices referring only to property damage have no safety alert symbol. These notices shown below are graded according to the degree of danger.

DANGER

indicates that death or severe personal injury **will** result if proper precautions are not taken.

WARNING

indicates that death or severe personal injury **may** result if proper precautions are not taken.

CAUTION

with a safety alert symbol, indicates that minor personal injury can result if proper precautions are not taken.

CAUTION

without a safety alert symbol, indicates that property damage can result if proper precautions are not taken.

NOTICE

indicates that an unintended result or situation can occur if the relevant information is not taken into account.

If more than one degree of danger is present, the warning notice representing the highest degree of danger will be used. A notice warning of injury to persons with a safety alert symbol may also include a warning relating to property damage.

Qualified Personnel

The product/system described in this documentation may be operated only by **personnel qualified** for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these products/systems.

Proper use of Siemens products

Note the following:

WARNING

Siemens products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Siemens. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

Trademarks

All names identified by ® are registered trademarks of Siemens AG. The remaining trademarks in this publication may be trademarks whose use by third parties for their own purposes could violate the rights of the owner.

Disclaimer of Liability

We have reviewed the contents of this publication to ensure consistency with the hardware and software described. Since variance cannot be precluded entirely, we cannot guarantee full consistency. However, the information in this publication is reviewed regularly and any necessary corrections are included in subsequent editions.

Table of contents

1	Introduction.....	7
1.1	Purpose of this documentation.....	7
1.2	History.....	7
1.3	Notes on warranty.....	7
1.4	Environmental protection.....	8
2	Safety notes.....	9
2.1	Precondition for use.....	9
2.2	Improper device modifications.....	9
2.3	Qualified personnel for hazardous area applications.....	9
2.4	Transport/Storage.....	10
3	Description.....	11
3.1	Applications.....	11
3.2	Product features.....	12
3.3	SITRANS P280 WirelessHART design.....	13
3.4	Operating principle.....	16
3.5	Battery.....	17
3.6	WirelessHART.....	17
3.6.1	Overview.....	17
3.6.2	WirelessHART.....	18
3.7	HART maintenance port.....	20
4	Commissioning (hardware).....	21
4.1	Overview commissioning.....	21
4.2	Identify unit.....	22
4.3	Assignment/determination of network access parameters.....	24
4.4	Inserting / removing the battery.....	25
4.5	Quick Start.....	28
5	Operation (hardware).....	29
5.1	Overview.....	29
5.2	Keypad.....	30
5.3	Digital display.....	31
5.4	Menu structure.....	32
5.5	Operating the local user interface.....	33

5.5.1	Input of alphanumeric string (input example).....	33
5.5.2	Input of numeric string (input example).....	35
5.5.3	Increase/decrease parameter value (input example).....	36
5.5.4	Setting list values.....	36
5.5.4.1	Single selection.....	36
5.5.4.2	Multiple selection.....	37
5.5.5	Use of key combinations.....	39
5.6	Parameter descriptions.....	39
5.6.1	"1 Quick start".....	39
5.6.1.1	"1.1 Network ID".....	39
5.6.1.2	"1.2 Network key".....	39
5.6.1.3	"1.3 Device name".....	40
5.6.1.4	"1.4 Transmission rate".....	40
5.6.1.5	"1.5 HART modem".....	40
5.6.1.6	"1.6 Connect network".....	40
5.6.2	"2 Settings".....	41
5.6.2.1	"2.1 Display".....	41
5.6.2.2	"2.2 Device name".....	42
5.6.2.3	"2.3 Press. set." pressure settings.....	42
5.6.2.4	"2.4 Temp. unit" (temperature unit).....	45
5.6.2.5	"2.5 Restart".....	45
5.6.2.6	"2.6 Reset device".....	46
5.6.3	"3 Diagnostics".....	47
5.6.3.1	"3.1 Identification".....	47
5.6.3.2	"3.2 Connection info".....	47
5.6.3.3	"3.3 Network info".....	47
5.6.3.4	"3.4 Device status".....	47
5.6.3.5	"3.5 Version".....	48
5.6.4	"4 Communication".....	48
5.6.4.1	"4.1 Radio".....	48
5.6.4.2	"4.2 Maintenance Port".....	50
5.6.5	"5 Security".....	51
5.6.5.1	"5.1 Active / inactive".....	51
5.6.5.2	"5.2 PIN input".....	51
5.6.5.3	"5.3 Change PIN".....	51
5.6.5.4	"5.4 Set level 0".....	51
5.6.5.5	"5.5 Timeout".....	52
5.6.6	"6 Language".....	52
5.7	Setting language.....	53
5.8	Canceling the password protection.....	54
5.9	Quick Start.....	55
5.10	Connect/disconnect.....	57
5.11	Pressure measurement.....	59
5.12	Increase service life.....	61
5.13	Protected from unauthorized access.....	62
5.14	Set HART functions of the HART maintenance port.....	64

6	Installing / mounting.....	65
6.1	Safety guidelines.....	65
6.2	Installation and connection guidelines.....	67
6.3	Mounting positions.....	68
6.4	Installing / mounting the device without mounting bracket.....	69
6.5	Installing / mounting the device with mounting bracket.....	69
6.6	Changing the display orientation.....	71
7	Connecting.....	73
7.1	Connect external devices to the HART maintenance port.....	73
8	Alarm, error, and system messages.....	75
8.1	Overview of messages and symbols.....	75
9	Troubleshooting/FAQs.....	77
9.1	Password forgotten?.....	77
9.2	Returning of battery.....	78
9.3	Return process for battery-operated devices.....	78
9.4	Technical support.....	79
A	Appendix.....	81
A.1	Technical data.....	81
A.1.1	General technical data.....	81
A.1.2	Input.....	81
A.1.3	Output.....	82
A.1.4	Measuring accuracy.....	82
A.1.5	Ambient conditions.....	82
A.1.6	Constructional design.....	82
A.1.7	Communication.....	83
A.1.8	Power supply.....	83
A.1.9	Certificates and approvals.....	83
A.2	Dimension drawings.....	84
A.2.1	SITRANS P280 for absolute pressure.....	84
A.2.2	SITRANS P280 for relative pressure.....	86
A.3	Spare parts/accessories.....	88
	Index.....	89

Introduction

1.1 Purpose of this documentation

These instructions contain all information required to commission and use the device. It is your responsibility to read the instructions carefully prior to installation and commissioning. In order to use the device correctly, first review its principle of operation.

The instructions are aimed at persons mechanically installing the device, connecting it electronically, configuring the parameters and commissioning it, as well as service and maintenance engineers.

1.2 History

The most important changes in the documentation when compared with the respective previous edition are given in the following table.

Edition	Remark
01 10/2009	First edition
02 10/2010	Was never published.
03 04/2012	<ul style="list-style-type: none">• Enhanced options for positioning the antenna.• Range of settings for transmission rate increased.• Technical specifications > input revised.

1.3 Notes on warranty

The contents of this manual shall not become part of or modify any prior or existing agreement, commitment or legal relationship. The sales contract contains all obligations on the part of Siemens as well as the complete and solely applicable warranty conditions. Any statements regarding device versions described in the manual do not create new warranties or modify the existing warranty.

The content reflects the technical status at the time of publishing. Siemens reserves the right to make technical changes in the course of further development.

1.4 Environmental protection

Recycling

Devices described in this programming manual can be recycled owing to the low content of noxious substances in their version. Please contact a certified waste disposal company for eco-friendly recycling and to dispose of your old devices.

Energy consumption

The devices are battery-operated, and have a very low power consumption. Depending on use, the battery life is several years.

Disposal of battery

Additional information is available under Returning of battery (Page 78).


Safety notes

2.1 Precondition for use

This device left the factory in good working condition. In order to maintain this status and to ensure safe operation of the device, observe these instructions and all the specifications relevant to safety.

Observe the information and symbols on the device. Do not remove any information or symbols from the device. Always keep the information and symbols in a completely legible state.

2.2 Improper device modifications

 WARNING
Improper device modifications Danger to personnel, system and environment can result from modifications to the device, particularly in hazardous areas. <ul style="list-style-type: none">• Only carry out modifications that are described in the instructions for the device. Failure to observe this requirement cancels the manufacturer's warranty and the product approvals.

2.3 Qualified personnel for hazardous area applications

Qualified personnel for hazardous area applications

Persons who install, assemble, commission, operate and service the device in a hazardous area must have the following specific qualifications:

- They are authorized, trained or instructed in operating and maintaining devices and systems according to the safety regulations for electrical circuits, high pressures and aggressive as well as hazardous media.
- They are authorized, trained, or instructed in carrying out work on electrical circuits for hazardous systems.
- They are trained or instructed in maintenance and use of appropriate safety equipment according to the pertinent safety regulations.

2.4 Transport/Storage

Make sure that transport damages are prevented through proper packaging!

Devices/replacement parts should be returned in their original packaging. If the original packaging is no longer available, please ensure that all shipments are properly packaged to provide sufficient protection during transport.

We cannot assume any costs for additional expenses resulting from transport damages.

Description

3.1 Applications

Pressure measurement

SITRANS P280 WirelessHART is a battery-operated pressure transducer for remote applications. You use this device to measure the absolute or relative pressures of the following media:

- Gases (aggressive, non-aggressive and dangerous gases)
- Vapors
- Liquids

The pressure transducer is operated under commercial conditions in the following industries:

- Chemical industry
- Power industry
- District heating
- Water supply and water treatment
- Food industry
- Iron and cement industry
- Pharmaceuticals
- Biotechnology

Communication

The device uses radio communication to communicate with other WirelessHART devices. Such communication requires use of the HART protocol V7.1. SITRANS P280 WirelessHART meets the following requirements:

- Setup of self organizing, wireless sensor networks
- Data exchange with other WirelessHART devices over distances of up to 250 m.
- Later installation without cabling
- Overcoming structural obstructions using the signal path.

3.2 Product features

The device has the following features:

- Absence of all cabling:
 - Wireless communication via wireless HART
 - Battery operation
- Local user interface with display and keys for efficient on-site operation
- Energy saving functions
- Display with backlight
- Rotatable display: flexible selection of mounting position
Changing the display orientation (Page 71)
- Integral HART maintenance port
- Antenna can be folded by 90°. Range of rotation: approx. 360°.
- Simple configuration with SIMATIC PDM
- Housing complies with IP65.

3.3 SITRANS P280 WirelessHART design

Device versions

The following external characteristics help you identify the different device versions for absolute and relative pressure measurement:




Figure 3-1 Distinguishing features

External design using SITRANS P280 absolute pressure measurement as an example




Figure 3-2 SITRANS P280 design example

Antenna

The device antenna can be folded to an angle of 90°. In addition, the antenna can be rotated approx. 360°. Two stops limit the range of adjustment.

Process connections

The device versions for absolute and relative pressure measurement are equipped with the following process connections:




Figure 3-3 Overview SITRANS P280 / process connections

3.4 Operating principle

Function

The input pressure is converted into an electrical signal by the sensor. This signal is amplified by the measuring amplifier and digitized in an analog-to-digital converter.

The digital signal is analyzed in a microcontroller and corrected with regard to linearity.

The measurement value will then be available to the HART Master via Hart-FSK as well as WirelessHART.

The specific measuring cell calibration data are stored in an EEPROM.

3.5 Battery

The very low energy consumption of the device means that a battery service life of up to 5 years is possible. The current charging level of the battery is shown in the device's digital display. If a critical charging level is reached, the device also sends this condition as part of the "Extended Status Byte" to the host control system.

Other repair or maintenance measures are not required on the device. You can find supplementary information on this under Inserting / removing the battery (Page 25) and Alarm, error, and system messages (Page 75).




Figure 3-4 High-capacity battery

3.6 WirelessHART

3.6.1 Overview

WirelessHART	
Wireless standard	IEEE 802.15.4-2006 @ 250 kbps
Frequency band	2.4 GHz
Data transmission	Frequency spread procedure (per packet basis)
Transmission range	Up to 250 m (visual connection)
Power supply	• Battery

WirelessHART	
Network topologies	<ul style="list-style-type: none"> • Meshed network • Star topology • Combination of both topologies
HART specification	HART protocol V7.1 HART - IEC 61158 E DDL - IEC 61804-3

3.6.2 WirelessHART

Fundamentals

Wireless HART is a fieldbus standard of the HART Communication Foundation and permits radio-based networking of field devices.

The radio transmission is based on the wireless communication standard IEEE 802.15.4-2006 (ISM band, 2.4 GHz).

The data transmission is appropriately encrypted using the Advanced Encryption Standard (AES 128). Data transmission as well as parameterization of the field devices involved is thus protected.

The data transmission is coordinated by the TDMA procedure (Time Division Multiplex Access). Signals from different transmitters are then only transmitted on the common bus within specific time slots, or the radio stations are synchronized with a sampling rate of 10 ms.

Interferences from other radio stations also using the 2.4 GHz band are minimized by application of a frequency spread procedure.

Properties

Field devices communicating using wireless HART can be connected into a meshed network:

- The wireless HART gateway obtains information from each field device involved in the wireless HART network concerning the respective adjacent devices.
- The network manager in the wireless HART gateway organizes the network on the basis of this information.

The field devices present on the network are both signal sources and repeaters. A message is passed on from the transmitting field device via the connected field devices until the wireless HART gateway is reached. If a network station fails or if a hindrance prevents a message from being passed on, the data is automatically transmitted via alternative routes.

If an additional field device is integrated into an existing network, it must be authenticated.




Figure 3-5 Meshed wireless HART network (example)

The transmission distance from station to station without barriers (line-of-sight) is up to 250 m. Significantly longer distances can be covered if the field devices of a network are spatially positioned in sequence.

3.7 HART maintenance port

The HART maintenance port is a HART communications interface via which the device can be parameterized and adjusted. You will need the following hardware and software:

- A HART communicator. Or:
- A PG / PC with HART modem, an appropriate parameterization tool (e.g. SIMATIC PDM) and the corresponding EDD.
- Appropriate cables

Note

Scope of supply

The accessories required for operation via the HART maintenance port are not included in the scope of supply of the device. Further information on SIMATIC PDM can be found on the Internet at:

SIMATIC PDM (<http://www.automation.siemens.com/w2/automation-technology-process-device-manager-pdm-3695.htm>)

Further information

Information on connecting/operating external devices and additional parameterization tools can be found in the respective documentation.

The following photo shows the contacts of the HART maintenance port for connecting a HART modem or HART communicator:




Figure 3-6 HART maintenance port

Commissioning (hardware)

4.1 Overview commissioning

Requirements

- You have unpacked the device.
- The device does not exhibit any visible damages.

Procedure


The commissioning of the transducer takes place in the following steps:

1. Identify unit (Page 22)
2. Assignment/determination of network access parameters (Page 24)
3. Inserting / removing the battery (Page 25)
4. Quick Start (Page 28)

4.2 Identify unit

Layout of the rating plate

The rating plates attached to the device housing contain important information on the product and its rated conditions. These will help you identify your device:



- | | |
|---|---|
| ① Manufacturer | ② Product name |
| ③ Product group | ④ Order number |
| ⑤ • Measuring point number (Y15)
• Measuring point message (Y16) | ⑥ Electrical data |
| ⑦ Information on field communication | ⑧ • Maximum permitted relative or absolute pressure
• Burst pressure |
| ⑨ Serial number of the device | ⑩ Degree of protection |
| ⑪ Place of manufacture | ⑫ Version |
| ⑬ CE mark | |

Figure 4-1 SITRANS P280 rating plate (right)




Figure 4-2 SITRANS P280 rating plate (left)

4.3 Assignment/determination of network access parameters

Note

Gateway

The device is able to establish a connection to all common wireless HART gateways. Refer to the gateway's documentation for information on logging-in of the device on the gateway.

Procedure

If you use the IE-WSN/PA-Link wireless HART gateway from Siemens, the following applies:

1. Make sure that a firmware version ≥ 3.8 is installed on the gateway.
2. Determine the network ID of your wireless HART network which is set in the gateway.
3. Determine the network key of the existing wireless HART network which is set in the gateway. The network key consists of 32 hexadecimal characters, {0, 1, 2, 3, 4, 5, 6, 7, 8, 9, a, b, c, d, e, f}.
Valid network keys are, for example:
 - 44555354 - 4e455457 - 4f524b53 - 524f434b
 - 195e0000 - 00000000 - 00000000 – 00000000
4. Continue with the commissioning: Inserting / removing the battery (Page 25) .

4.4 Inserting / removing the battery

CAUTION

Heating-up of device housing

Depending on the process connection, the device housing may become very hot during operation.

Before replacing the battery, check the danger of burns. Wear gloves if necessary when opening the housing.

CAUTION

Battery

Use of non-approved or damaged batteries may result in damage to the device or in the environment.

Only use the battery type approved by the manufacturer. Before fitting a battery, check that it is not damaged.

Note

Qualified personnel

Fitting and removal of the battery must only be carried out by qualified personnel. Additional information is available under: Qualified personnel for hazardous area applications (Page 9) .

Note

Positioning of battery

Selection of the mounting position influences the service life of the battery. Position the battery such that the positive pole points vertically upwards as far as possible following installation of the device.

Note

Depassivation of battery

As a result of longer service lives, it is possible that your battery may become passivated. If you fit a passivated battery in your device, a low battery service life is shown in the display. Reason: Passivated batteries do not initially provide their full capacity.

During operation, the device depassivates the battery, and the display of the battery service life is corrected accordingly.

Requirements

- Battery replacement during operation: the deep sleep function is activated.

Inserting the battery




Figure 4-3 Inserting the battery

1. Open the device.
To do this, unscrew the cover at the rear of the device.
2. Plug the battery connector ③ into the socket.
3. Insert the battery.
 - Position the battery centrally between the two clips ①.
 - Make sure when inserting that neither the battery cable nor the sensor cable is routed close to the internal thread. Following insertion of the battery, the cable ② must be routed underneath it.
 - Clip in the battery between the two holders ①.
4. Make sure the battery is securely latched in the holders. Otherwise press on the battery again.
5. Check that the battery and sensor cables are positioned sufficiently far away from the thread of the housing cover. This avoids damage when screwing on the cover.
6. Fitting of the battery has been completed. Screw the cover back into place.

Removing the battery

1. Activate the deep sleep function.
Use of key combinations (Page 39)
2. Wait for a further 30 s.
3. Open the device.
To do this, unscrew the cover at the rear of the device.
4. Remove the battery from its holder.
5. Hold the battery, and carefully unplug the connector.

4.5 Quick Start

Requirement

Note

Factory default settings

In the as-delivered state, the following default settings are made:

- Display language: "English"
 - Password protection "Active"
-

Procedure

You complete commissioning using the settings in menu "1 Quick start". Your transmitter is connected to the wireless HART network in the process. The following steps are required:

1. Set display language if necessary.
Menu: Set Setting language (Page 53).
2. Cancel the password protection. Setting: "Inactive".
Parameter "5.1 Active / inactive" (Page 51).
3. Set quick start parameters.
Menu: "1 Quick start" (Page 39) .

Operation (hardware)

5.1 Overview

The following options are available to operate the transducer:

- Operating the transducer with external devices connected to the HART Maintenance Port, for example:
 - HART communicator
 - Engineering tool, e.g. SIMATIC PDMOperation of the device with SIMATIC PDM requires an E²DD. Additional information is available in the Internet at SIMATIC PDM (<http://www.automation.siemens.com/w2/automation-technology-process-device-manager-pdm-3695.htm>).
- Local operation using the local user interface (LUI).
The local user interface is a digital display with three buttons to access all functions of the device with the help of menus.

This chapter includes all information you need to operate the device with the local user interface.

NOTICE
If you have changed the basic functions of the pressure transducer to meet your particular needs, the display and the measurement output could be set so that they may not indicate the actual process pressure. Therefore, check the basic parameters before commissioning.

5.2 Keypad

Layout




Figure 5-1 Keypad

The keypad is located underneath a screwed flap which you open with a Phillips screwdriver.

Function of the keys M, ↑ and ↓


The keys are assigned the following functions:

Key	Meaning	Functions
M	MENU / ENTER	<ul style="list-style-type: none"> • Open selected menus. • Save a selection. • Save modified values.
↑	UP / ESCAPE	<ul style="list-style-type: none"> • Leave a menu following selection of first menu entry. • Select the next higher menu entry or list entry. • Increase a parameter value. • Shift cursor by one step forward in order to select a character.
↓	DOWN	<ul style="list-style-type: none"> • Select the next lower menu entry or list entry. • Decrease a parameter value. • Shift cursor by one step backward in order to select a character.


5.3 Digital display

Views


The digital display provides access to information, navigation and setting options.



Measured value view



Navigation view (multi-layer menu structure)



Parameter view

Note

The temperature dependency of the digital display

The display will respond rather slowly to changes when the ambient temperatures drop below -10 °C. Ambient temperatures of more than +60 °C will reduce the contrast of the digital display.

5.4 Menu structure

Layout

The menu structure includes main and submenus. The main menu comprises a total of six entries:

- | | | | |
|---|---------------------------|---|-----------------------------|
| 1 | "1 Quick start" (Page 39) | 4 | "4 Communication" (Page 48) |
| 2 | "2 Settings" (Page 41) | 5 | "5 Security" (Page 51) |
| 3 | "3 Diagnostics" (Page 47) | 6 | "6 Language" (Page 52) |

"1 Quick start"

This menu includes all settings essential for commissioning (commissioning in minimum configuration).

- | | | | |
|-----|--------------|-----|--------------------|
| 1.1 | Network ID | 1.4 | Transmission rate |
| 1.2 | Network code | 1.5 | HART modem |
| 1.3 | Device name | 1.6 | Network connection |

"2 Settings"

You use this menu and its submenus to adjust the device to the concrete rated conditions.

- | | | | |
|-----|------------------|-----|----------------------|
| 2.1 | Display | 2.4 | Temp. unit |
| 2.2 | Device name | 2.5 | Cold restart |
| 2.3 | Pressure setting | | Resetting the device |

"3 Diagnostics"

Use this menu to query communication and device information:

- | | | | |
|-----|------------------------|-----|---------|
| 3.1 | Identification | 3.4 | Status |
| 3.2 | Connection information | 3.5 | Version |
| 3.3 | Network information | | |

"4 Communication"

Use this menu to make the network and communication settings (HART modem):

- 4.1 Wireless
- 4.2 Maintenance port

"5 Security"

Use this menu to make security settings.

- | | | | |
|-----|------------------|-----|----------------|
| 5.1 | Active/inactive | 5.4 | Set to level 0 |
| 5.2 | Entering the PIN | 5.5 | Time-out |
| 5.3 | Changing the PIN | | |

"6 Language"

Use this menu to select the display language. The following languages are available:

- | | |
|-----|---------|
| 6.1 | German |
| 6.2 | English |

5.5 Operating the local user interface

5.5.1 Input of alphanumeric string (input example)

Principle

Alphanumeric values, e.g. the device name, are entered character-by-character. When you open the setting option, the first character is focused and can be changed.

- Select the desired character by pressing the ↑ or ↓ key.
- The cursor is moved forward by one digit by pressing the **M** key. The selected character is applied.

Procedure

The device name "MSK-012E" is to be entered.

1. Open the parameter to be changed, in this case: "2.2 Device name" (Page 42)



2. Enter the first character:
Select/change: Press ↑ or ↓ key until the letter "M" is displayed.
Retain/apply: Press **M** key. Reaction: the cursor moves on.



3. Repeat step 2 until the desired string is complete. Following input of the eighth character, the cursor is positioned on the Enter symbol.



4. Leave input option. Press the **M** key.



5.5.2 Input of numeric string (input example)

Principle


Numeric strings, e.g. the network ID, are entered character-by-character. When you open the setting option, the first number is focused:

- Increase or decrease the value by pressing the ↑ or ↓ key.
- The number is accepted and the cursor moved forward by one digit by pressing the **M** key.
- If you press the **M** key when the last digit has been reached, the complete string is saved and the input option closed.

Procedure

The network ID is to be set to the value "61428".


1. Open the parameter to be changed. Here: "1.1 Network ID" (Page 39)



2. Increase first number:

Press the ↑ key 1 x. Then press the **M** key.


The number has been increased, and the cursor moved on by one digit.



3. Decrease second number:


Press the ↓ key 1 x. Then press the **M** key.

The number has been decreased, and the cursor moved on by one digit.



4. Save complete, modified network ID:

Press the **M** key 3 x. The input option is exited.



5.5.3 Increase/decrease parameter value (input example)


Principle

Parameter values can be increased (↑ key) or reduced (↓ key) by a fixed value within a certain range. When you open the setting option, the currently set value is focused.


Procedure

The transmission rate is to be changed from 8 to 25 s.


1. Open the parameter to be changed. Here: "1.4 Transmission rate" (Page 40)



2. Keep the ↑ key pressed until the parameter value "25" is set.



3. Save the desired value: Press the **M** key.



5.5.4 Setting list values

5.5.4.1 Single selection

Principle


When you open the setting option, the cursor marks the currently set value.

Select a value from the list by moving the cursor using the ↑ or ↓ key. To save the change, subsequently press the **M** key.


Procedure

Rotate display orientation by 180° compared to normal view.


1. Open the parameter to be changed. Here: "2.1.3 Orientation" (Page 42)



2. Shift the cursor downward using the ↓ key:



3. Save changes: Press the **M** key.



5.5.4.2 Multiple selection

Principle


When opening, none of the selectable or previously set values is marked by the cursor. You can set all, none or only one value as the fixed setting.

None of the list entries is marked when opening. The first list entry is marked by pressing the **M** key. The checkboxes of the list can also be activated or deactivated by pressing the **M** key. To save and exit, press the ↑ key 3 x.


Procedure

All functions of the burst display are deactivated, and are to be switched on again.


1. Open the parameter to be changed. Here: "2.1.2 Burst display" (Page 41)




2. Set cursor to the first list entry. Press the **M** key.




3. Select the first list value. Press the **M** key.



4. Mark the next list entry using the cursor. Press the **↓** key.



5. Accept the selected list entry. Press the **M** key.



6. The changes are automatically saved when closing. To do this, press the **↑** key 3 x.

5.5.5 Use of key combinations

Deep sleep function

- Activation/deactivation:
Keep the **M** and **↑** keys pressed simultaneously for >10 s.
 - If you activate this function, the power consumption of the device is reduced to a minimum. The display is switched off, and the connection to the wireless HART network is interrupted.
 - If the function is deactivated, the display is switched on again and your device automatically attempts to reestablish the connection to the wireless HART network.

Backlight function

- Activation/deactivation:
Press the **↑** and **↓** keys simultaneously.
 - The display backlight is activated, and is automatically deactivated after approx. 20 s.

5.6 Parameter descriptions

5.6.1 "1 Quick start"

5.6.1.1 "1.1 Network ID"

Factory setting:	1229
Setting range:	• 00001 ... 65535
Purpose:	Assign network ID
Description:	Commissioning requirement. Password-protected function. For security reasons, always change this during commissioning.

5.6.1.2 "1.2 Network key"

Factory setting:	-
Setting range:	• 32-digit, hexadecimal
Purpose:	Assign network key
Description:	Commissioning requirement. Must be assigned and set by the user during commissioning.

5.6.1.3 "1.3 Device name"

Factory setting:	-
Setting range:	-
Purpose:	Specify device name
Description:	The device name can contain up to 8 characters. Select the characters by pressing the ↑ or ↓ key.

5.6.1.4 "1.4 Transmission rate"

Factory setting:	60 s
Setting range:	<ul style="list-style-type: none"> 8 to 255 s
Purpose:	Set transmission rate.
Description:	<p>Setting of time intervals at which the transmitter sends measured values. Increase or decrease the parameter value by pressing the ↑ or ↓ key.</p> <p>Use the parameter "2.1.2 Burst display" (Page 41) to visualize the set transmission rate.</p>

5.6.1.5 "1.5 HART modem"

Factory setting:	HART active
Setting range:	<ul style="list-style-type: none"> Active Inactive
Purpose:	Activate/deactivate HART maintenance port.
Description:	<p>The HART maintenance port is always activated in the factory default setting. In order to increase the battery service life, we recommend the "Inactive" setting.</p> <p>Select the list entries using the ↑ or ↓ key. Accept the setting by pressing the M key.</p>

5.6.1.6 "1.6 Connect network"

Requirements:	<ol style="list-style-type: none"> Wireless HART gateway is prepared. The following parameters have been set: <ul style="list-style-type: none"> "1.1 Network ID" (Page 39) "1.2 Network key" (Page 39) "1.3 Device name" (Page 40) "1.4 Transmission rate" (Page 40) "1.5 HART modem" (Page 40)
Factory setting:	-
Setting range:	<ul style="list-style-type: none"> START

Purpose:	Connect device to wireless HART network.
Description:	Start establishment of the connection by pressing the M key. Establishment of the connection is displayed in the measured value view. The supplementary message is deleted when the connection has been established successfully.

5.6.2 "2 Settings"

5.6.2.1 "2.1 Display"

"2.1.1 Contrast"

Factory setting:	3 bars
Setting range:	<ul style="list-style-type: none"> "-" ... "+" (6-step bar display)
Purpose:	Set contrast of digital display.
Description:	<p>You can change the contrast setting using a vertical 6-step bar display.</p> <p>Press the ↑ (+) or ↓ (-) keys.</p> <p>Accept setting: Press M key.</p>

"2.1.2 Burst display"

Requirement:	The following parameter has been set: "1.4 Transmission rate" (Page 40)
Factory setting:	-
Setting range:	<p>Set using 2 checkboxes</p> <ul style="list-style-type: none"> Display on ("yes" / "no") Lighting ("yes" / "no")
Purpose:	Control display response.
Description:	<ul style="list-style-type: none"> Display on: If you select this setting, a measured value is output on the display each time it is transmitted. Lighting If you activate this function, the digital display is lit for approx. 1 second each time a measured value is transmitted. You can therefore establish at night whether your device is still working. <p>To change the settings:</p> <ul style="list-style-type: none"> First select the checkbox: Press M key. Activate the checkbox: Press M key. Change the checkbox: Press the ↑ or ↓ keys. Leave list and save: Press ↑ key 3 x.

"2.1.3 Orientation"

Factory setting:	Normal
Setting range:	Radio buttons <ul style="list-style-type: none"> • Normal • Rotated by 180°
Purpose:	Change orientation of digital display.
Description:	Improves the readability of the digital display in certain mounting positions.

5.6.2.2 "2.2 Device name"

Factory setting:	-
Setting range:	-
Purpose:	Specify device name
Description:	Corresponds to following parameter: "1.3 Device name" (Page 40)

5.6.2.3 "2.3 Press. set." pressure settings

"2.3.1 Set to 0"

Factory setting:	START
Setting range:	-
Purpose:	Correct offset in devices for relative pressure measurement.
Description:	<p>Deviations of the measuring cell will be compensated by shifting the characteristic curve. The currently measured pressure will be set as "0" value. The pressure value "0" will be displayed in the measured value view.</p> <ul style="list-style-type: none"> • Note: Setting of the parameter "2.3.3 Lower calibration" (Page 43) will overwrite the offset correction. <p>Start the function by pressing the M key. Exit the setting option with the buttons ↑ or ↓.</p>

"2.3.2 Unit"

Factory setting:	bar
Setting range:	Selection from a list: <ul style="list-style-type: none"> • bar • TORR • Gcm² • KGcm² • MPa • KPA • Pa • Psi • mmHG • mmH2O • FTH2O • inHG • inH2O
Purpose:	Setting the unit of measurement
Description:	Start the function by pressing the ↑ or ↓ buttons. Start the function by pressing the M key.

"2.3.3 Lower calibration"

Factory setting:	Curr. press. = Set pressure [BAR]
Setting range:	Increment/decrement: ±0,001
Purpose:	<ul style="list-style-type: none"> • Setting the set pressure value for the lower calibration: • Customized calibration / offset
Description:	<p>Adjusting the measured current pressure value to the actually existing pressure by increasing or decreasing the set pressure value.</p> <ul style="list-style-type: none"> • Increase the set pressure value with the ↑ button and decrease it with the ↓ button. • Accept the setting by pressing the M button. • Cancel or confirm with "OK" (↑ + M) <p>When you have set this parameter, the menu "2.3. Press. set." will also display the menu entry "2.3.4 Upper calibration" (Page 43).</p>

"2.3.4 Upper calibration"

Requirement	Parameter "2.3.3 Lower calibration" (Page 43) is set.
Factory setting:	Curr. press. = Set pressure [BAR]
Setting range:	Increment/decrement: ±0,001

5.6 Parameter descriptions

Purpose:	<ul style="list-style-type: none"> Setting the set pressure value for the upper calibration: Customized calibration / offset
Description:	<p>Adjusting the measured current pressure value to the actually existing pressure by increasing or decreasing the set pressure value.</p> <ul style="list-style-type: none"> Increase the set pressure value with the ↑ button and decrease it with the ↓ button. Accept the setting by pressing the M button. Cancel or confirm with "OK" (↑ + M)

"2.3.5 Reset calibration" (reset calibration)

Requirement:	<p>The following parameter settings have been altered:</p> <ul style="list-style-type: none"> "2.3.3 Lower calibration" (Page 43) "2.3.4 Upper calibration" (Page 43)
Factory setting:	START
Setting range:	-.
Purpose:	Resetting the factory calibration: Curr. press. = Set pressure
Description:	<p>Start the function by pressing the M key.</p> <p>Following the reset, the menu entry "Upper calibration" will no longer be displayed.</p>

"2.3.6 Electr. damping" (electrical damping)

Factory setting:	0 s
Setting range:	0 to 30 s
Purpose:	Measuring pressure as an average value: Determine the time constant.
Description:	<p>Specify the time constant required to calculate the average value. The time constant is the time period in which a certain number of measurements is taking place.</p> <p>The maximum is one pressure measurement per second.</p> <p>If you set the electrical damping to "0 s", the function will be deactivated. The value of the parameter "2.3.7 Qty. Measured values" (number of measured values) (Page 44) will be automatically set to the value "1".</p> <p>Set the required damping value: Do this by pressing the buttons ↑ or ↓. Accept the setting by pressing the M button.</p> <p>Set the parameters "2.3.7 Qty. Measured values" (number of measured values) (Page 44).</p>

"2.3.7 Qty. Measured values" (number of measured values)


Requirement:	Parameter "2.3.6 Electr. damping" (electrical damping) (Page 44) is set.
Factory setting:	1
Setting range:	0 ... 30

Purpose:	Measuring pressure as an average value: Specify number of measured values per time constant.
Description:	<p>The mean pressure value is calculated based on the measured values within the time constant. The maximum is one measurement per second.</p> <p>Setting rule: Number measured values \leq Electr. damping. Example:</p> <ul style="list-style-type: none"> • Number measured values = 10 • Electr. damping = 30 s <p>⇒ Pressure measurement at intervals of 3 s.</p> <p>Increase the with the \uparrow button and decrease it with the \downarrow button. Accept the setting by pressing the M button.</p>

5.6.2.4 "2.4 Temp. unit" (temperature unit)

Factory setting:	°C
Setting range:	<ul style="list-style-type: none"> • °C • °F
Purpose:	Specify the unit for the measurement of the internal device temperature.
Description:	<p>Select the required unit by pressing the \uparrow or \downarrow buttons.</p> <p>Accept the setting by pressing the M button.</p>

5.6.2.5 "2.5 Restart"

 CAUTION	
<p>Personal injury and damage to property</p> <p>Activation of this function during operation interrupts the connection between the transmitter or router and the network. Depending on the topology, this may result in failure of the wireless HART network and also personal injury and/or damage to property. Therefore:</p> <ul style="list-style-type: none"> • Avoid inadvertent operations: Make sure that the PIN input is always activated. • Check on the gateway whether the device can be removed from the network without resulting in a failure or danger. 	

Requirements:	<ul style="list-style-type: none"> • Removal of device without danger is guaranteed • PIN input function is active
Factory setting:	-
Setting range:	START


5.6 Parameter descriptions

Purpose:	<ul style="list-style-type: none"> Restart device Corresponds to interruption in power supply
Description:	<p>The network and address parameters are not deleted. Following the interruption in communication, the device attempts to reintegrate into the wireless HART network.</p> <p>Start this function by pressing the M key. Then: Execution depends on input of PIN!</p>

See also

"4.1.5 Disconnect network" (Page 49)

5.6.2.6 "2.6 Reset device"

 CAUTION	
Personal injury and damage to property	
<p>Activation of this function during operation interrupts the connection between the transmitter or router and the network. Depending on the topology, this may result in failure of the WirelessHART network and also personal injury and/or damage to property. Therefore:</p>	
<ul style="list-style-type: none"> Avoid inadvertent operations: Make sure that the password input is always activated. Check on the gateway whether the device can be removed from the network without resulting in a failure or danger. 	

Requirements:	<ul style="list-style-type: none"> Removal of device without danger is guaranteed: "4.1.5 Disconnect network" (Page 49) Password function is active.
Factory setting:	-
Setting range:	<ul style="list-style-type: none"> START
Purpose:	<ul style="list-style-type: none"> Shut down device Reset all parameters to factory settings Delete network and address parameters
Description:	<p>Start this function by pressing the M key. Then: Execution depends on input of password.</p> <p>If you activate this function, you shut down the device. Reconnection into a WirelessHART network requires a new startup. See: Quick Start (Page 28)</p> <p>If you reestablish the factory state by setting this parameter, a changed PIN is also reset. In order to subsequently reconfigure the device, you require the factory-set PIN "4711". See: Protected from unauthorized access (Page 62)</p>

5.6.3 "3 Diagnostics"

5.6.3.1 "3.1 Identification"

Factory setting:	Read only
Setting range:	-
Purpose:	Identification of device in network
Description:	Display of: <ul style="list-style-type: none">• Device name• Device ID

5.6.3.2 "3.2 Connection info"

Factory setting:	Read only
Setting range:	-
Purpose:	Scan connection status
Description:	Display of: <ul style="list-style-type: none">• Network status: "Connected" / "Not connected"• Adjacent stations: Number of adjacent stations of device

5.6.3.3 "3.3 Network info"

Factory setting:	Read only
Setting range:	-
Purpose:	Scan information on network
Description:	Display of: <ul style="list-style-type: none">• Network ID• Network name

5.6.3.4 "3.4 Device status"

Factory setting:	Read only
Setting range:	-
Purpose:	Scan indicators of device status
Description:	Display of: <ul style="list-style-type: none">• Internal temperature of device in °C or °F• Remaining battery service life in days

5.6.3.5 "3.5 Version"

Factory setting:	Read only
Setting range:	-
Purpose:	Check version
Description:	Display of: <ul style="list-style-type: none">• Hardware version number• Software version number

5.6.4 "4 Communication"

5.6.4.1 "4.1 Radio"

"4.1.1 Network ID"

Factory setting:	1229
Setting range:	<ul style="list-style-type: none">• 00001 ... 65535
Purpose:	Assign network ID
Description:	Commissioning requirement. Password-protected function. Corresponds to parameter "1.1 Network ID" (Page 39) .

"4.1.2 Network key"

Factory setting:	-
Setting range:	<ul style="list-style-type: none">• 32-digit, hexadecimal
Purpose:	Assign network key
Description:	Commissioning requirement. Password-protected function. Corresponds to parameter "1.2 Network key" (Page 39) .

"4.1.3 Connect network"


Requirements:	<ul style="list-style-type: none">• Wireless HART gateway is prepared.• All parameters required for commissioning are set. See menu "1 Quick start" (Page 39)
Factory setting:	-
Setting range:	<ul style="list-style-type: none">• START

Purpose:	Connect device to wireless HART network.
Description:	Start establishment of the connection by pressing the M key. Establishment of the connection is displayed in the measured value view. The supplementary message is deleted when the connection has been established successfully. Corresponds to parameter "1.6 Connect network" (Page 40) .

"4.1.4 Transmission rate"

Factory setting:	60 s
Setting range:	<ul style="list-style-type: none"> 8 to 3600 s
Purpose:	Set transmission rate.
Description:	Setting of time intervals at which the transmitter sends measured values. Increase or decrease the parameter value by pressing the ↑ or ↓ key. Corresponds to parameter "1.4 Transmission rate" (Page 40) .

"4.1.5 Disconnect network"

 CAUTION	
Personal injury and damage to property Activation of this function during operation interrupts the connection between the transmitter or router and the network. Depending on the topology, this may result in failure of the wireless HART network and also personal injury and/or damage to property. Therefore: <ul style="list-style-type: none"> Avoid inadvertent operations: Make sure that the password input is always activated. Check on the gateway whether the device can be removed from the network without resulting in a failure or danger. 	

Requirements:	<ul style="list-style-type: none"> Removal of device from the wireless HART network without danger is guaranteed PIN input function is active
Factory setting:	-
Setting range:	<ul style="list-style-type: none"> START
Purpose:	Interrupt communication of device with other network stations
Description:	Preparation for removal of device. The network and address parameters are not deleted. Through activation of the parameter "4.1.3 Connect network" (Page 48) the device reestablishes the connection. Start this function by pressing the M key. Then: Execution depends on input of PIN!

5.6.4.2 "4.2 Maintenance Port"

"4.2.1 HART modem"

Factory setting:	HART active
Setting range:	<ul style="list-style-type: none"> • Active • Inactive
Purpose:	Activate/deactivate HART maintenance port.
Description:	<p>The HART maintenance port is always activated in the factory default setting. In order to increase the battery service life, we recommend the "Inactive" setting.</p> <p>Select the list entries using the ↑ or ↓ key. Accept the setting by pressing the M key.</p> <p>Corresponds to parameter "1.5 HART modem" (Page 40) .</p>

"4.2.2 HART address"

Factory setting:	0
Setting range:	0 ... 255
Purpose:	Address device for communication via HART maintenance port
Description:	<p>Assign a HART address for HART communication with external PG / PC or HART communicator via the HART maintenance port.</p> <p>Increase or decrease the address using the ↑ or ↓ keys. Accept the setting by pressing the M key.</p>

"4.2.3 Number response preambles"

Factory setting:	5
Setting range:	5 ... 20
Purpose:	<ul style="list-style-type: none"> • Set number of response preambles • Protection of HART communication
Description:	<p>Sending and receipt of a specific number of preambles signals that data transmission has actually commenced between PG / PC and the field device (via the HART maintenance port).</p> <p>The communication stations thus differentiate between data and interfering signals.</p> <p>Increase or decrease the number of preambles using the ↑ or ↓ keys. Accept the setting by pressing the M key.</p>

5.6.5 "5 Security"

5.6.5.1 "5.1 Active / inactive"

Factory setting:	Inactive
Setting range:	<ul style="list-style-type: none"> Active Inactive
Purpose:	Activate/deactivate PIN input as security function
Description:	If you activate this function, certain parameters and functions can only be set or executed following input of a PIN.

5.6.5.2 "5.2 PIN input"

Factory setting:	-
Setting range:	-
Purpose:	<ul style="list-style-type: none"> Enter master pin Unlock device
Description:	Unlocking of device following loss of PIN. You can obtain the required master pin from the Siemens Hotline. Keep ready the information from the nameplate. You will find additional information on this in the section Troubleshooting/ FAQs (Page 77).

5.6.5.3 "5.3 Change PIN"

Factory setting:	0000
Setting range:	0000 ... 9999
Purpose:	<ul style="list-style-type: none"> Change factory-set PIN "4711" Define own PIN
Description:	<p>Your own PIN overwrites the factory-set PIN "4711". If you forget your own PIN, you must unlock the device using the master PIN, see "5.2 PIN input" (Page 51)</p> <p>Enter your own PIN using the ↑ or ↓ keys. Confirm input using the M key.</p>

5.6.5.4 "5.4 Set level 0"

Requirement:	<ul style="list-style-type: none"> "5.1 Active / inactive" (Page 51) is "Active". "5.5 Timeout" (Page 52) is "Off". The PIN has been entered in order to set a protected parameter: Device in safety level 1.
Factory setting:	Off

5.6 Parameter descriptions

Setting range:	<ul style="list-style-type: none">• Off• On
Purpose:	<ul style="list-style-type: none">• Activate PIN input function again• Exclude unauthorized users• Set device to safety level 0 (no changes to configuration possible).
Description:	If you select the setting "On", the PIN input is immediately switched on again. You must enter the PIN again in order to change protected parameters. The device is then in safety level 1, and changes to the configuration are possible.

5.6.5.5 "5.5 Timeout"

Factory setting:	On
Setting range:	<ul style="list-style-type: none">• Off• On
Purpose:	Limit time for changes to password-protected functions.
Description:	If you select the setting "On", you limit the time span for changes to further parameters or functions protected by a PIN. If you select the setting "Off", protected functions remain changeable following the PIN input. In order to protect your device, you must manually trigger "5.4 Set level 0" (Page 51).

5.6.6 "6 Language"

Factory setting:	English
Setting range:	<ul style="list-style-type: none">• English• German
Purpose:	Language selection
Description:	With this parameter you specify the language of the menu.

5.7 Setting language


Requirements

- The device is ready for commissioning
- You are acquainted with the principles of operation: Operating the local user interface (Page 33)

Procedure

Changing the language setting

- Menu: "6 Language" (Page 52)
- The default setting is "English".



5.8 Canceling the password protection

Requirements


- The device is ready for commissioning
- You are acquainted with the principles of operation: Operating the local user interface (Page 33)

Procedure

You must deactivate the PIN input function so that the device configuration can be changed.


If the device is in the factory state, the PIN input function is preset.

1. Parameter. Call "5.1 Active / inactive" (Page 51).




2. Begin with input of the PIN.


If the device is in the factory state, enter the preset PIN "4711".



3. Select setting "Inactive", and confirm.



4. The PIN input function is canceled.



Change further parameters, or call the measured value view.


5.9 Quick Start

Requirements


- The device has been prepared for connection with the WirelessHART network.
Commissioning (hardware) (Page 21)
- You are familiar with the operating principles: Operating the local user interface (Page 33)

Procedure

1. Enter Network ID.
Parameters: "1.1 Network ID" (Page 39)
Use only the network ID you have entered in the gateway.




2. Enter the network code.
Parameters: "1.2 Network key" (Page 39)
Use only the network code you have entered in the gateway.




3. Specify the device name.
Parameters: "1.3 Device name" (Page 40)
If the device integrates itself in the WirelessHART network, then the device name will be transmitted to the gateway. You can change the device name later even through the gateway.



4. Specify the transmission rate for measured values.
Parameters: "1.4 Transmission rate" (Page 40)



5. Deactivate the HART Maintenance Port.
Parameters: "1.5 HART modem" (Page 40)
You reduce the power consumption by deactivating the HART Maintenance Port and increase the battery life at the same time.




6. Establish the connection to the gateway.
Parameters: "1.6 Connect network" (Page 40)



5.10 Connect/disconnect

Overview

The status of the connection to the WirelessHART network is indicated by the three connection modes ①, ② and ③.



- ① Connected: Establishment of connection successful. Digital display in measurement view.
- ② Network connection disconnected.
- ③ Establishment of connection being attempted ("Force join-Mode").

Figure 5-2 Connection modes

Connection mode "Wireless HART network disconnected"

Trigger:

- An existing connection to the gateway has been interrupted, e.g. by parameter "4.1.5 Disconnect network" (Page 49)




Connection mode "Connect"

The device attempts to establish a connection to the WirelessHART network. Trigger:

- Attempt to connect started via external devices:
 - HART modem
 - Control system
- The device is started up.
Quick start: Menu "1 Quick start" (Page 39)



- The attempt to connect is forced.
Connect network: Parameter "4.1.3 Connect network" (Page 48)



Connection mode "Connected"

The change to the measured value view signals that a connection to the WirelessHART network exists.

5.11 Pressure measurement

Requirement

You are familiar with the operating principles: Operating the local user interface (Page 33)

Procedure

Note


Preconfigured device

Your device has been preconfigured in the factory for a certain pressure range. This means you will only have to set a few parameters.


1. If you want to use the device for measuring relative pressure:

Correct the offset (optional):

Parameters: "2.3.1 Set to 0" (Page 42)




2. Select the unit of measurement.
Parameters: "2.3.2 Unit" (Page 43)



3. Sensor calibration:

Setting the value for the lower calibration (optional)

Parameters: "2.3.3 Lower calibration" (Page 43)



Note


Restriction

If you alter the value for the lower calibration, then you will overwrite the offset correction.

Setting the value for the upper calibration (optional).

Setting option will only be displayed after altering the "lower limit".

Parameters: "2.3.4 Upper calibration" (Page 43)



Reset sensor calibration.

Parameters: "2.3.5 Reset calibration" (reset calibration) (Page 44)




4. Setting the measured value processing (optional).


If you set these parameters, then the measured value will be determined as a mean value.

Set the following parameters for this purpose:

"2.3.6 Electr. damping" (electrical damping) (Page 44)



"2.3.7 Qty. Measured values" (number of measured values) (Page 44)



5.12 Increase service life

Requirement

- You have executed the quick start function: Quick Start (Page 55)
- You are acquainted with the principles of operation: Operating the local user interface (Page 33)


Procedure

1. Switch off HART maintenance port.

Parameter:

- "1.5 HART modem" (Page 40) or
- "4.2.1 HART modem" (Page 50)


Switching-off the HART maintenance port reduces the energy consumption and thus reduces the battery service life.



2. Set "Burst display" function.

Parameter: "2.1.2 Burst display" (Page 41)

The battery service life is highest if both checkboxes are deactivated.




5.13 Protected from unauthorized access

Requirement


You are acquainted with the principles of operation: Operating the local user interface (Page 33)

Procedure

1. Change factory-set PIN.
Parameter: "5.3 Change PIN" (Page 51)




2. Activate/deactivate PIN input
Parameter: "5.1 Active / inactive" (Page 51)
"Active": PIN input is active.
"Inactive": PIN input is canceled.



3. Set timeout if applicable.

Parameter: "5.5 Timeout" (Page 52)

"On": Time window for reactivation of PIN input. Following expiry of the timeout, the PIN input is reactivated automatically.



4. Set user privileges to level 0.

Parameter: "5.4 Set level 0" (Page 51)

Interrupts the timeout. Renewed input of the PIN is required in order to change the device configuration.



Note

Response when resetting the device

If you reestablish the factory state by setting the parameter "2.6 Reset device" (Page 46), the changed PIN is also reset. In order to subsequently reconfigure the device, you require the factory-set PIN "4711".

5.14 Set HART functions of the HART maintenance port

Overview


Using the procedure described below, you can prepare your transmitter for the connection of external devices to the HART maintenance port.

Requirement


You are acquainted with the principles of operation: Operating the local user interface (Page 33)

Procedure


1. Switch on HART maintenance port.
Parameter:
"4.2.1 HART modem" (Page 50)
The energy consumption is increased when the HART maintenance port is switched on. Deactivate the parameter when you have finished with the connection to the external HART device.



2. Define HART address for communication with the external device.
Parameter: "4.2.2 HART address" (Page 50)




3. Define number of HART response preambles.
Parameter: "4.2.3 Number response preambles" (Page 50)



Installing / mounting

6.1 Safety guidelines

<p> WARNING</p> <p>Escape of dangerous media</p> <p>The device can also be used in processes with dangerous media. Hot and/or toxic media under pressure may cause severe personal injury or damage to property if they escape. Observe the appropriate regulations for equipment under pressure, especially in the following cases:</p> <ul style="list-style-type: none"> • Design • Installation/removal • Operation
<p>CAUTION</p> <p>Limitation of degree of protection</p> <p>If the device is open, IP65 protection is no longer guaranteed.</p>
<p>CAUTION</p> <p>Damage to device through disregard of mounting guidelines</p> <p>The following mounting guidelines apply in order to avoid damage:</p> <ul style="list-style-type: none"> • Make sure prior to mounting that the device is appropriate with regard to the process connection, media compatibility, temperature resistance and measuring range. Check that the required technical specifications agree with the data on the nameplate. Technical data (Page 81) . • The device housing must always be closed following mounting.
<p>CAUTION</p> <p>Damage to device through impermissible temperature effects</p> <p>A temperature outside the permissible limits will damage your device. For data on the temperature limits, refer to Ambient conditions (Page 82) .</p> <p>Make sure that the permissible ambient temperature at the mounting location is not exceeded. Additionally protect your device from direct heating effects.</p>

NOTICE
Reduced accuracy through unfavorable mounting location Selection of the mounting location influences the measuring accuracy. Therefore mount the device as close as possible to the measuring point. Make sure that the mounting location is free from vibrations and other negative environmental influences.

6.2 Installation and connection guidelines

Process connection

Make sure that the selected device is suitable for your particular process. Take into consideration especially compatibility, temperature resistance and measuring range.

Any required seals must be suitable for the process connection and be resistant to the measured substance.

Select a position for the connection on the process side so that the antenna of the connected WirelessHART device will be pointing straight up. This positioning will ensure optimum sending and receiving conditions.

6.3 Mounting positions

The adjustability of display and antenna make for flexible integration of the device into your process. Select installation positions in which the antenna will point straight up. This installation ensures optimum integration into the WirelessHART network.

If the positive terminal of the battery is also pointing up after the installation, then battery life will be extended.

Do not install the device in positions or places in which the specified device limits will be violated. The respective information is available in Technical data (Page 81) .

The installation location is to be as follows:

- Easily accessible
- Vibration-free
- Directly located in the measuring point

6.4 Installing / mounting the device without mounting bracket

Requirements

- The battery is installed.
- All housing covers are fastened.

Procedure

You can fasten the transmitter directly on the process connection. The device comes equipped with a connection featuring thread design G $\frac{1}{2}$ or $\frac{1}{2}$ " NPT.

1. Always use the correct tools.
2. Fasten the process connector of the device.
Do not turn the housing.
Tighten the process connection with a wrench.


NOTICE
Safe process connection If the process connection is subject to severe vibrations or shocks, we recommend that you install / mount the device with a mounting bracket. Additional information is available under: Installing / mounting the device with mounting bracket (Page 69)

6.5 Installing / mounting the device with mounting bracket

Requirements

- The battery is installed.
- All housing covers are fastened.

Overview



- | | |
|-----------------------------------|-------------------------------|
| ① Housing with fastening bores | ⑤ Nut M8 |
| ② Installation angle (90° rotary) | ⑥ Screw thread M8 or 5/16 UNF |
| ③ Screw thread M8 or 5/16 UNF | ⑦ Pole |
| ④ Washer DIN 125 - 8.4 | ⑧ Pole clamp |

Fasten the transmitter mounting bracket using the two screws provided. You can fasten the mounting bracket as follows:

- On a wall or a mounting frame using two screws
- On a vertical or horizontal mounting tube (Ø 50 to 60 mm) using a tube bracket

Procedure

1. Secure the mounting bracket ② with pole clamp ⑧, washers ④ and nuts ⑤ on the pole ⑦.
2. Push the housing ① onto the mounting bracket ②.
3. Tighten the screws ③ and ⑥.

6.6 Changing the display orientation


You can subsequently rotate the display unit of your device by 90°.

Requirement

- You have removed the battery.
- You are protected against electrostatic discharging.

Procedure

1. Unscrew the front cover of the housing.
2. Unscrew the M3 x 14 screws from the display unit housing.
3. Remove the display unit to the front.
4. Rotate the display unit by 90° and replace onto the base:



5. Insert the mounting screws into their holes.
Tighten the screws with a torque of approx. 1 to 2 Nm.

Connecting

7.1 Connect external devices to the HART maintenance port

Requirement

The following conditions must be fulfilled before connecting external devices:

- The battery is fitted and supplies the transmitter with power.
- The HART maintenance port is active.
- The external device is set up for the connection.

Procedure




Figure 7-1 Terminals on the HART maintenance port

7.1 Connect external devices to the HART maintenance port

1. Open the device.
To do this, unscrew the cover at the rear of the device.
2. Secure the terminals of the HART modem or HART communicator on the HART maintenance port.
3. Begin with changing of the settings.
The following applies if you use a SIMATIC PDM Engineering Tool:
 - Connect the HART modem to your PG / PC.
 - Establish a connection between Engineering Tool and device.
4. Remove the connection: Carry out steps 1 to 3 in the reverse order.

Alarm, error, and system messages

8.1 Overview of messages and symbols

Convention

In this section, "message" is used as a general term for all information that is shown on the digital display. In particular, messages include the following:

- Alarm messages
- fault indications
- Status information

Display behavior on local user interface

Messages are shown in the measurement view of the digital display.

The digital display shows an active alarm as a combination of symbols and text. The symbol displays the type and severity of the alarm. The symbol for the most serious alarm will flash.













Figure 8-1 Display response of messages (example)

Characteristics of messages

The following table summarizes the possible types of messages in an overview. The number of dots assigned to the symbol defines the importance level of the message.

Icon	Message	Description/Significance
	Maintenance alarm	e.g.: Sensor breakage, memory error, device malfunction <ul style="list-style-type: none"> • Aging reserve of device or fitting expired • A sudden fault has occurred The measured values are invalid. Device maintenance is necessary to reestablish the functionality.
	Maintenance demanded	e.g.: Electronics fault, internal temperature error
	Maintenance required	Maintenance is recommended.
	Process value alarm	One or more process values are creating a problem. Therefore the device is not measuring any process values.

8.1 Overview of messages and symbols

	Process value warning	There is a problem with one or more process values. Measured values are produced but they may be uncertain. Example: A process value exceeds the device specification.
	Process value tolerance	One or more process values have reached the tolerance limit. Only adjustable using an engineering tool, e.g. SIMATIC PDM.
	Data exchange	Device establishes connection to wireless HART network.
	Data exchange	Connection to wireless HART network not available.
	Write protection ON	Key locking is set, or device functions are password-protected.
	Battery exhausted	Critical battery status. Battery must be replaced.
	Low battery capacity	Charging level approx. 33%
	Sufficient battery capacity	Charging level approx. 66%
	Fully charged battery	Charging level 100%

Troubleshooting/FAQs

9.1 Password forgotten?

How do I get a new master PIN?


If you have changed the factory-set PIN and the device refuses to accept a different PIN, please phone your Siemens partner.

You will then be provided with a new master PIN to unlock your device. The following information is required:


- Device type
- Serial No. of the device

How do I unlock the device?

1. Call the input option.
Parameter: "5.2 PIN input" (Page 51)



2. Enter master PIN and confirm.



3. Define new PIN.
Parameter: "5.3 Change PIN" (Page 51)

9.2 Returning of battery

Procedure

NOTICE

Environmental protection

The high-performance battery used contains lithium thionyl chloride. The internal components of the battery must not pollute the environment. Do not dispose of the battery in the domestic refuse.

Please contact your regional partner concerning the procedure for replacing old batteries. You can find additional information in the Internet at:

Regional contacts (<http://www.automation.siemens.com/partner/guiselectcountry.asp?lang=en®id=def&aktstep=3&contid=1>)

9.3 Return process for battery-operated devices



WARNING

Remove the battery unit before returning the device

Before returning the device, remove the battery unit. Battery units must not be returned. Lithium thionyl chloride high-performance batteries belong to dangerous goods class 9: Miscellaneous hazardous materials and substances. Read the accompanying safety data sheet.

Return procedure

Attach the bill of lading, returned goods document and decontamination certificate in a firmly affixed clear plastic pouch on the outside of the packaging.

Required forms

- **Bill of lading**
- **Return document** with the following information:
Auto-Hotspot
 - Product (item description)
 - Number of returned devices/replacement parts
 - Reason for returning the item(s)
- **Decontamination declaration**
Auto-Hotspot
With this declaration you warrant "that the device/replacement part has been carefully cleaned and is free of residues. The device/replacement part does not pose a hazard for humans and the environment."
If the returned device/replacement part has come into contact with poisonous, corrosive, flammable or water-contaminating substances, you must thoroughly clean the device/replacement part before returning it, in order to ensure that all hollow areas are free of hazardous substances. Check the item after it has been cleaned.
Any devices/replacement parts which are returned without a decontamination declaration will be cleaned at your cost before further processing.

The form is available on the Internet.

9.4 Technical support

Technical Support

You can contact Technical Support for all IA and DT products:

- Via the Internet using the **Support Request**:
Support request (<http://www.siemens.com/automation/support-request>)
- E-mail (<mailto:support.automation@siemens.com>)
- **Phone**: +49 (0) 911 895 7 222
- **Fax**: +49 (0) 911 895 7 223

Further information about our technical support is available in the Internet at
Technical Support (<http://www.siemens.com/automation/csi/service>)

Service & Support on the Internet

In addition to our documentation, we offer a comprehensive knowledge base online on the Internet at:

Services & Support (<http://www.siemens.com/automation/service&support>)

There you will find:

- The latest product information, FAQs, downloads, tips and tricks.
- Our newsletter, providing you with the latest information about your products.

- A Knowledge Manager to find the right documents for you.
- Our bulletin board, where users and specialists share their knowledge worldwide.
- You can find your local contact partner for Industry Automation and Drives Technologies in our partner database.
- Information about field service, repairs, spare parts and lots more under "Services."

Additional Support

Please contact your local Siemens representative and offices if you have any questions about the products described in this manual and do not find the right answers.

Find your contact partner at:

Partner (<http://www.automation.siemens.com/partner>)

A signpost to the documentation of the various products and systems is available at:

Instructions and Manuals (<http://www.siemens.com/processinstrumentation/documentation>)

See also

Product information on SITRANS P in the Internet (<http://www.siemens.com/sitransp>)

Further information on wirelessHART (<http://www.siemens.com/wirelesshart>)

Appendix

A.1 Technical data

A.1.1 General technical data

Pressure transmitter	
Type	SITRANS P280 WirelessHART Low Power operation
Measured variables	<ul style="list-style-type: none"> • Relative pressure • Absolute pressure
Enclosure	<ul style="list-style-type: none"> • Die-cast aluminum • Nameplate made of stainless steel
Weight	1.5 kg
Dimensions	See Dimension drawings (Page 84)
Operator interface	<ul style="list-style-type: none"> • Local User Interface (LUI) <ul style="list-style-type: none"> – Digital display – Menu control – 3 control keys
Degree of protection	IP65

A.1.2 Input

Sensor	
<ul style="list-style-type: none"> • Sensor type 	<ul style="list-style-type: none"> • Piezoresistive ceramic sensor • Dry measuring cell
<ul style="list-style-type: none"> • Sensor characteristics 	Linear
<ul style="list-style-type: none"> • Sensor supply 	Not available
Relative pressure and absolute pressure	
<ul style="list-style-type: none"> • Span ¹⁾ 	Max. perm. test pressure
0 ... 1.6 bar(0 ... 23 psi)	4 bar (58 psi)
0 ... 10 bar (0 ... 145 psi)	20 bar (290 psi)
0 ... 50 bar (0 ... 725 psi)	100 bar (1450 psi)
0 ... 200 bar (0 ... 2900 psi)	400 bar (5801 psi)
0 ... 320 bar (0 ... 4641 psi)	640 bar (9282 psi)
Units	Mbar, bar, m4H2O, iH2O, ATM, TORR, Gcm ² , KGcm ² , MPa, KPA, Pa, Psi, mmHG, mmH2O, FTH2O, inHG, inH2O

¹⁾ The maximum span corresponds to the maximum permissible working pressure.

A.1.3 Output

Output signal	<ul style="list-style-type: none"> • Wireless HART, frequency 2.4 GHz • HART maintenance port
---------------	---

A.1.4 Measuring accuracy

Operating temperature	40 °C ... +80 °C / -40 °F ... +176 °F
Measuring accuracy	
• incl. hysteresis and repeatability	±0.325 % or better
• Measuring accuracy (25 °C)	<ul style="list-style-type: none"> • < 0.25 % of the measuring range limit (typ.) • < 0.50 % of the measuring range limit (maximum)
Long-term drift	• < 0.25 % of the measuring range limit annually
Ambient temperature effect	±0.025 % / 10 K

A.1.5 Ambient conditions

Ambient temperature (operation)	-40 ... +80 °C (-40 ... +176 °F)
Storage temperature (without battery)	-40 ... +85 °C (-40 ... +185 °F)
Relative humidity	<95 %
Climate class	4K4H, in accordance with EN 60721-3-4 (stationary use at locations not protected against weather)
EMC conditions	In accordance with DIN EN 61326
Degree of protection	IP65/NEMA 4

A.1.6 Constructional design

Enclosure	Die-cast aluminum
Impact resistance	Corresponds to DIN EN 60068-2-29 / 03.95
Vibration resistance	<ul style="list-style-type: none"> • DIN EN 60068-2-6/12.07 • $20 \leq f \leq 2000$ Hz • $0.01 \text{ g}^2/\text{Hz}$
Weight	ca. 1.6 kg (without battery)

Dimensions (W x H x D)	See Dimension drawings (Page 84)
Process connection / threading	<ul style="list-style-type: none"> • G$\frac{1}{2}$ • $\frac{1}{2}$"-14 NPT

A.1.7 Communication

Wireless standard	In conformance with wireless HART V7.1
Transmitter frequency band	2.4 GHz (ISM)
Transmission range	
<ul style="list-style-type: none"> • Outdoors 	Up to 250 m (visual connection)
<ul style="list-style-type: none"> • Indoors 	Up to 50 m (depends on hindrances)
Interface	<ul style="list-style-type: none"> • Wireless HART maintenance port: Input/output for HART communication with HART modem • Antenna (wireless HART)

A.1.8 Power supply

Power supply	
Battery	Lithium thionyl D-cell
Battery voltage	3.6 V DC
Max. current (I_{max})	100 mA
Battery life	Up to 5 years with optimum conditions of use and activation of all energy-saving functions


A.1.9 Certificates and approvals

Device safety	IT standard IEC / EN 60950-1:2006
Radio module FCC ID	SJC-M2140
Explosion protection	-


A.2 Dimension drawings

A.2.1 SITRANS P280 for absolute pressure

With process connection G1½




With process connection 1/2" NPT




A.2.2 SITRANS P280 for relative pressure

With process connection G $\frac{1}{2}$



With process connection 1/2" NPT



A.3 Spare parts/accessories

Accessories	
Item	Order number
Battery	7 M P 1 9 9 0 - 0 A A 0 0
Mounting bracket	
Steel	7 M F 4 9 9 7 - 1 A C
Stainless steel	7 M F 4 9 9 7 - 1 A J
Cover (die-cast aluminum)	
Without inspection window	7 M F 4 9 9 7 - 1 B B
With inspection window	7 M F 4 9 9 7 - 1 B E

Index

Backlight function
Hotkeys, 39

A

Additional Support, 80

B

Battery
Depassivation, 25
Installing, 26
Removing, 27
Battery life, 8
Battery unit, 78

C

Correct usage, (See improper device modifications)
Customer Support Hotline, 79

D

Dangerous goods, 78
Deep sleep function
Activation, 27
Hotkeys, 39
Default settings
Display language, 28
Password protection, 28
Depassivation
Battery, 25

E

Energy consumption, 8
Environmental protection, 8

H

History, 7

Hotkeys
Backlight function , 39
Deep sleep function, 39
Hotline, 79

I

Improper device modifications, 9
Internet, 79

M

Mean value
Number of measured values, 60
Mounting bracket, 69

P

PIN
Default PIN, 54

Q

Qualified personnel, 9

R

Recycling, 8

S

Safety data sheet, 78
Service, 79
Support, 79

